




ULTRA
SERIES

BRUSHLESS PLUNGE ROUTER

Original Operating Instructions

IDU WR-B8



To reduce the risk of injury, the user must read and understand the Operator's Manual before using this product. Save these instructions for future reference.

5. **Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
6. **Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
7. **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of dust collection can reduce dust-related hazards.
8. **Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** Careless action can cause severe injury within a fraction of a second.

Power tool use and care

1. **Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
2. **Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
3. **Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
4. **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
5. **Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.
6. **Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
7. **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.
8. **Keep handles and grasping surfaces dry, clean and free from oil and grease.** Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.
9. **When using the tool, do not wear cloth work gloves which may be entangled.** The entanglement of cloth work gloves in the moving parts may result in personal injury.

Battery tool use and care

1. **Recharge only with the charger specified by the manufacturer.** A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.

2. **Use power tools only with specifically designated battery packs.** Use of any other battery packs may create a risk of injury and fire.
3. **When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.** Shorting the battery terminals together may cause burns or a fire.
4. **Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help.** Liquid ejected from the battery may cause irritation or burns.
5. **Do not use a battery pack or tool that is damaged or modified.** Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
6. **Do not expose a battery pack or tool to fire or excessive temperature.** Exposure to fire or temperature above 130 °C may cause explosion.
7. **Follow all charging instructions and do not charge the battery pack or tool outside the temperature range specified in the instructions.** Charging improperly or at temperatures outside the specified range may damage the battery and increase the risk of fire.

Service

1. **Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.
2. **Never service damaged battery packs.** Service of battery packs should only be performed by the manufacturer or authorized service providers.
3. **Follow instruction for lubricating and changing accessories.**
4. **Keep handles dry, clean and free from oil and grease.**

Cordless trimmer safety warnings

1. **Hold power tool by insulated gripping surfaces, because the cutter may contact hidden wiring.** Cutting a "live" wire may make exposed metal parts of the power tool "live" and shock the operator.
2. **Use clamps or another practical way to secure and support the workpiece to a stable platform.** Holding the work by your hand or against the body leaves it unstable and may lead to loss of control.
3. **Wear hearing protection during extended period of operation.**
4. **Handle the trimmer bits very carefully.**
5. **Check the trimmer bit carefully for cracks or damage before operation. Replace cracked or damaged bit immediately.**
6. **Avoid cutting nails. Inspect for and remove all nails from the workpiece before operation.**
7. **Hold the tool firmly.**
8. **Keep hands away from rotating parts.**
9. **Make sure the trimmer bit is not contacting the workpiece before the switch is turned on.**

SPECIFICATIONS

Model:	IDU WR-B8
Collet chuck capacity	6mm / 8mm
No load speed	12,000 - 28,000/min
Rated voltage	D.C. 20 V
Net weight	1.8-2.1 kg

- Due to our continuing program of research and development, the specifications herein are subject to change without notice.
- Specifications and battery pack may differ from country to country.

SAFETY WARNINGS

General power tool safety warnings

⚠ WARNING: Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

Work area safety

1. **Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
2. **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
3. **Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

Electrical Safety

1. **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
2. **Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
3. **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.

4. **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.
5. **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
6. **If operating a power tool in a damp location is unavoidable, use a ground fault circuit interrupter (GFCI) protected supply.** Use of a GFCI reduces the risk of electric shock.
7. **Power tools can produce electromagnetic fields (EMF) that are not harmful to the user.** However, users of pacemakers and other similar medical devices should contact the maker of their device and/or doctor for advice before operating this power tool.

Personal Safety

1. **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
2. **Use personal protective equipment. Always wear eye protection.** Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.
3. **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
4. **Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.


FUNCTIONAL DESCRIPTION

CAUTION: Always be sure that the tool is switched off and the battery pack is removed before adjusting or checking function on the tool.

Installing or removing battery pack

CAUTION: Always switch off the tool before installing or removing of the battery pack.

CAUTION: Hold the tool and the battery pack firmly when installing or removing battery pack. Failure to hold the tool and the battery pack firmly may cause them to slip off your hands and result in damage to the tool and battery pack and a personal injury.




► 1. Red indicator 2. Button 3. Battery pack

CAUTION: Always install the battery pack fully until the red indicator cannot be seen. If not, it may accidentally fall out of the tool, causing injury to you or someone around you.

CAUTION: Do not install the battery pack forcibly. If the battery pack does not slide in easily, it is not being inserted correctly.

Indicating the remaining battery capacity

Only for battery packs with the indicator



► 1. Indicator lamps 2. Check button

Press the check button on the battery pack to indicate the remaining battery capacity. The indicator lamps light up for few seconds.

NOTE: Depending on the conditions of use and the ambient temperature, the indication may differ slightly from the actual capacity.

The status displayed on the switch panel and the remaining battery capacity is shown in the following table.

LED indicator status	Remaining battery capacity
	About 70% or more
	About 30% - 70%
	About less than 20%

NOTE:

- Before checking the remaining battery capacity, be sure to stop the tool.

Tool / battery protection system

The tool is equipped with a tool/battery protection system. This system automatically cuts off power to the motor to extend tool and battery life. The tool will automatically stop during operation if the tool or battery is placed under one of the following conditions:

Overload protection

When the battery is operated in a manner that causes it to draw an abnormally high current, the tool automatically stops without any indication. In this situation, turn the tool off and stop the application that caused the tool to become overloaded. Then turn the tool on to restart.

- Before using the tool on an actual workpiece, let it run for a while. Watch for vibration or wobbling that could indicate improperly installed bit.
- Be careful of the trimmer bit rotating direction and the feed direction.
- Do not leave the tool running. Operate the tool only when hand-held.
- Always switch off and wait for the trimmer bit to come to a complete stop before removing the tool from workpiece.
- Do not touch the trimmer bit immediately after operation; it may be extremely hot and could burn your skin.
- Do not smear the tool base carelessly with thinner, gasoline, oil or the like. They may cause cracks in the tool base.
- Use trimmer bits of the correct shank diameter suitable for the speed of the tool.
- Some material contains chemicals which may be toxic. Take caution to prevent dust inhalation and skin contact. Follow material supplier safety data.
- Always use the correct dust mask/respirator for the material and application you are working with.

SAVE THESE INSTRUCTIONS.

WARNING: DO NOT let comfort or familiarity with product (gained from repeated use) replace strict adherence to safety rules for the subject product. MISUSE or failure to follow the safety rules stated in this instruction manual may cause serious personal injury.

Symbols

The followings show the symbols used for tool.

	volts
	direct current
	no load speed
	revolutions or reciprocation per minute

Important safety instructions for battery cartridge

- Before using battery cartridge, read all instructions and cautionary markings on (1) battery charger, (2) battery, and (3) product using battery.
- Do not disassemble battery cartridge.
- If operating time has become excessively shorter, stop operating immediately. It may result in a risk of overheating, possible burns and even an explosion.

- If electrolyte gets into your eyes, rinse them out with clear water and seek medical attention right away. It may result in loss of your eyesight.
- Do not short the battery cartridge:
 - Do not touch the terminals with any conductive material.
 - Avoid storing battery cartridge in a container with other metal objects such as nails, coins, etc.
 - Do not expose battery cartridge to water or rain.

A battery short can cause a large current flow, overheating, possible burns and even a breakdown.
- Do not store the tool and battery cartridge in locations where the temperature may reach or exceed 50 °C (122 °F).
- Do not incinerate the battery cartridge even if it is severely damaged or is completely worn out. The battery cartridge can explode in a fire.
- Be careful not to drop or strike battery.
- Do not use a damaged battery.
- The contained lithium-ion batteries are subject to the Dangerous Goods Legislation requirements.

For commercial transports e.g. by third parties, forwarding agents, special requirement on packaging and labeling must be observed. For preparation of the item being shipped, consulting an expert for hazardous material is required. Please also observe possibly more detailed national regulations.

Tape or mask off open contacts and pack up the battery in such a manner that it cannot move around in the packaging.

- Follow your local regulations relating to disposal of battery.

SAVE THESE INSTRUCTIONS.

CAUTION: Only use ORIGINAL batteries.


Use of non-genuine batteries, or batteries that have been altered, may result in the battery bursting causing fires, personal injury and damage. It will also void the warranty for the tool and charger.

Tips for maintaining maximum

Battery life

- Charge the battery cartridge before completely discharged. Always stop tool operation and charge the battery cartridge when you notice less tool power.
- Never recharge a fully charged battery cartridge. Overcharging shortens the battery service life.
- Charge the battery cartridge with room temperature at 10 °C - 40 °C (50 °F - 104 °F). Let a hot battery cartridge cool down before charging it.
- Charge the battery cartridge if you do not use it for a long period (more than six months).

NOTICE: If the tool is not secured after closing the lock lever, tighten the hex nut, and then close the lock lever.




► 1. Hex nut

Adjusting cutting depth with the plunge router base


Optional accessory

1. Place the tool on the flat surface.
2. Select the stopper screw by rotating the stopper base.




► 1. Stopper screw 2. Stopper base

3. Loosen the stopper pole fixing nut, then pull up the stopper pole while pressing the feed button.




► 1. Stopper pole 2. Fixing nut 3. Feed button

4. Push down the tool until the tip of the trimmer bit touches the flat surface, and then turn the fixing lever to secure the tool.




► 1. Fixing lever 2. Trimmer bit

5. Press down the stopper pole while pressing the feed button until it contacts the stopperscrew.



► 1. Stopper pole 2. Stopper screw 3. Feed button

6. Slide the depth pointer so that the pointer indicates "0" on the scale.



► 1. Depth pointer

7. Adjust the cutting depth by pulling up the stopper pole while pressing the feed button.

Overheat protection


When the tool or battery is overheated, the tool stops automatically and the lamp blinks. In this case, let the tool and battery cool before turning the tool on again.

Overdischarge protection

When the battery capacity is not enough, the tool stops automatically. In this case, remove the battery from the tool and charge the battery.

Switch action

To turn on the tool, press the lock/unlock button. The tool turns into the standby mode. To start the tool, press the start/stop button in the standby mode. To stop the tool, press the start/stop button again. The tool turns into the standby mode. To turn off the tool, press the lock/unlock button in the standby mode.



► 1. Lock/unlock button 2. Start/stop button

NOTE: If the tool is left for 10 seconds without any operation in the standby mode, the tool automatically turns off and the lamp goes off.

NOTE: You can also stop and turn off the tool by pressing the lock/unlock button while the tool is operating.

Lighting up the front lamp

CAUTION: Do not look in the light or see the source of light directly.


To turn on the lamp, press the lock/unlock button. To turn off the lamp, press the lock/unlock button again.

NOTICE: When the tool is overheated, the lamp flickers. Cool down the tool fully before operating the tool again.

NOTE: Use a dry cloth to wipe the dirt off the lens of the lamp. Be careful not to scratch the lens of lamp, or it may lower the illumination.

Speed adjusting dial

The rotation speed of the tool can be changed by turning the speed adjusting dial. The table below shows the number on the dial and the corresponding rotation speed.



► 1. Speed adjusting dial

Number	Speed
1	12,000/min
2	16,000/min
3	20,000/min
4	24,000/min
5	28,000/min

NOTICE: If the tool is operated continuously at low speed for a long time, the motor will get overloaded, resulting in tool malfunction.

NOTICE: When changing the speed dial from "5" to "1", turn the dial counterclockwise. Do not turn the dial clockwise forcibly.


Electronic function

The tool is equipped with the electronic functions for easy operation.


- Constant speed control
The speed control function provides the constant rotation speed regardless of load conditions.
- Soft start
The soft-start function minimizes start-up shock, and makes the tool start smoothly.

Adjusting cutting depth with trimmer base


To adjust the cutting depth, open the lock lever, then move the tool base up or down by turning the adjusting screw. After the adjustment, close the lock lever firmly.



► 1. Lock lever 2. Adjusting screw




- 1. Shaft lock 2. Loosen 3. Tighten 4. Wrench 5. Collet nut



- 1. Wrench 2. Loosen 3. Tighten 4. Collet nut


NOTE: The shaft lock may not return to the original position when you tighten the collet nut at the installation of the trimmer bit. The shaft lock returns to the original position when you start the tool.



- 1. Shaft lock

Installing or removing the trimmer base


1. Open the lock lever of the trimmer base, then insert the tool into the trimmer base aligning the groove on the tool with the protrusion on the trimmer base.




- 1. Lock lever

2. Close the lock lever.


3. Attach the dust nozzle to the trimmer base, and then tighten the thumb screw.



- 1. Dust nozzle 2. Thumb screw




To remove the base, follow the installation procedure in reverse.




- 1. Stopper pole 2. Feed button

8. To perform fine adjustment of the cutting depth, turn the dial on the stopper pole so that it indicates "0".




- 1. Dial

9. Turn the head of the stopper pole to obtain the desired depth. To increase the depth, turn the head counterclockwise. To decrease the depth, turn the head clockwise.




- 1. Head of the stopper pole

10. Tighten the stopper pole fixing nut.



- 1. Fixing nut

11. Release the fixing lever.



- 1. Fixing lever


ASSEMBLY

CAUTION: Always be sure that the tool is switched off and the battery cartridge is removed before carrying out any work on the tool.

Installing or removing trimmer bit


NOTICE: Do not tighten the collet nut without inserting the bit. The collet cone may break.

Insert the trimmer bit all the way into the collet cone. Press the shaft lock and tighten the collet nut with the wrench or tighten the collet nut securely with the two wrenches. To remove the bit, follow the installation procedure in reverse.




► 1. Lock lever

8. Attach the base plate by tightening the screws.




► 1. Base plate

9. Insert the collet cone and the trimmer bit into the offset base, and then tighten the collet nut.



► 1. Trimmer bit 2. Collet nut 3. Collet cone


10. Insert the hex wrench into the hole of the offset base, and then tighten the collet nut with the wrench.



► 1. Collet nut 2. Wrench 3. Hexwrench

To remove the base, follow the installation procedure in reverse.

NOTE: You can also mount the belt to the pulley without removing the base plate as shown in the figure.




► 1. Pulley 2. Belt

Installing or removing the plunge base

Optional accessory

1. Open the lock lever of the plunge base, then insert the tool into the plunge base all the way aligning the groove on the tool with the protrusion on the plunge base.




► 1. Lock lever

Installing or removing the offset base


Optional accessory

1. Press the shaft lock, then loosen the collet nut.




► 1. Collet nut 2. Shaft lock 3. Wrench

2. Remove the collet nut and the collet cone.




► 1. Collet nut 2. Collet cone

3. Install the pulley on the tool by pressing the shaft lock and tightening the pulley with the wrench.




► 1. Wrench 2. Pulley 3. Shaft lock

4. Loosen the screws on the base plate, and then remove the base plate.




► 1. Base plate

5. Open the lock lever of the offset base, then insert the tool into the offset base.



► 1. Lock lever

6. Mount the belt to the pulley by rotating the belt manually.



► 1. Pulley 2. Belt


7. Close the lock lever.

Using the straight guide for circular work

For circular work, assemble the straight guide as shown in the figures. The minimum and maximum radius of circles to be cut (distance between the center of circle and the center of bit) are as follows:


- Minimum: 70 mm (2-3/4")
- Maximum: 221 mm (8-11/16")

For cutting circles between 70 mm (2-3/4") and 121 mm (4-3/4") in radius.



► 1. Center hole


For cutting circles between 121 mm (4-3/4") and 221 mm (8-11/16") in radius.



► 1. Center hole

NOTE: Circles between 172 mm (6-3/4") and 186 mm (7-5/16") in radius cannot be cut using this guide.

Align the center hole in the straight guide with the center of the circle to be cut. Drive a nail less than 6 mm (1/4") in diameter into the center hole to secure the straight guide. Pivot the tool around the nail in the clockwise direction.




► 1. Nail 2. Center hole

Using the templet guide

Optional accessory


The templet guide allows for repetitive cut with templet patterns by using a templet.

1. Loosen the screws on the base plate, and then remove the base plate from the trimmer base.
2. Place the templet guide on the base, and then attach the base plate by tightening the screws.



► 1. Base plate 2. Templetguide

3. Place the tool on the templet and move the tool with the templet guide sliding along the side of the templet.




► 1. Trimmer bit 2. Workpiece 3. Straightguide

NOTICE: Since excessive cutting may cause overload of the motor or difficulty in controlling the tool, the depth of cut should not be more than 3 mm (1/8") at a pass when cutting grooves. When you wish to cut grooves more than 3 mm (1/8") deep, make several passes with progressively deeper bit settings.

Using the straight guide


Optional accessory

1. Assemble the straight guide with the bolt and the wing nut.




► 1. Bolt 2. Wing nut

2. Attach the straight guide to the trimmer base with the clamp screw.




► 1. Clamp screw

3. Loosen the wing nut on the straight guide and adjust the distance between the bit and the straight guide. At the desired distance, tighten the wing nut.





► 1. Wing nut

4. Move the tool with the straight guide flush with the side of the workpiece.



If the distance (A) between the side of the workpiece and the cutting position is too wide for the straight guide, or if the side of the workpiece is not straight, the straight guide cannot be used. In this case, firmly clamp a straight board to the workpiece and use it as a guide against the trimmer base. Feed the tool in the direction of the arrow.






1. Use only the voltage specified on the charger.
 - 2 Before charging the battery, first connect the power cable to the mains and then connect the battery pack to the charger. After the battery has been fully charged, disconnect the power supply after removing the battery pack from the charger.
- This device is for indoor use only. Water, rain, or moisture should be avoided.
 - Do not expose the charger to rain, snow and other extreme weather conditions. Do not use the power tools in damp or wet locations.
 - Do not use the charger if it has been hit hard, dropped or damaged in any way, take it to an authorized customer service center.
 - Do not disassemble the charger. Bring it to customer service if it needs to be repaired or serviced. Incorrect assembly could result in electric shock or fire.

MAINTENANCE

CAUTION: Always be sure that the tool is switched off and the battery cartridge is removed before attempting to perform inspection or maintenance.


NOTICE: Never use gasoline, benzine, thinner, alcohol or the like. Discoloration, deformation or cracks may result.

To maintain product SAFETY and RELIABILITY, repairs, any other maintenance or adjustment should be performed by Authorized or Factory Service Centers, always using original replacement parts.



NOTE: The actual cut size on the workpiece is slightly different from the templet. The difference is the distance (X) between the trimmer bit and the outside of the templet guide. The distance (X) can be calculated by using the following equation:

$$\text{Distance (X)} = (\text{outside diameter of templet guide} - \text{trimmer bit diameter}) / 2$$




1. Trimmer bit
2. Templet guide
3. Distance (X)
4. Outside diameter of templet guide


Using the trimmer guide

Optional accessory

The trimmer guide allows for trimming curved side like veneers for furniture by moving the guide roller along the side of the workpiece.




1. Loosen the clamp screw, then install the trimmer guide on the trimmer base, and then tighten the clamp screw.




1. Clamp screw

2. Loosen the clamp screw and adjust the distance between the trimmer bit and the trimmer guide by turning the adjusting screw (1 mm (3/64") per turn). At the desired distance, tighten the clamp screw to secure the trimmer guide.



1. Adjusting screw
2. Clampscrew


3. Move the tool with the guide roller riding the side of the workpiece.



1. Workpiece
2. Bit
3. Guide roller

Part No.	Part Name.	Qty.
1	Left Housing	1
2	Battery Holder L	1
3	Battery Clamp	1
4	Label For Switch	1
5	Switch Button	1
6	Pcb Board	1
7	Battery Holder R	1
8	Screw St4*14	10
9	Right Housing	1
10	Stator	1
11	BALL-BEARING 608	1
12	Rotor	1
13	Circlip For Shaft	2
14	ball bearing 6003	1
15	wave washer $\phi 34 \times \phi 27 \times 0.4$	1
16	bearing sleeve	1
17	Alu main body	1
18	cap for shaft lock	1
19	spring	1
20	shaft lock	1
21	collet $\phi 6$	1
22	collet nut	1
23	head of the stopper pole	1
24	stopper pole	1
25	O ring	1
26	depth pointer	1
27	main stopper pole	1
28	handle	2
29	cap for handle	2
30	screw M6*30	2
31	elastic cylindrical pin	1
32	Lock lever	1
33	lock bolt	1
34	Square gasket	1
35	circlip for shaft 8	1
36	Limit washer	1
37	screw	1
38	Fixing lever	1
39	torsional spring	1
40	Locking screw	1
41	cylindrical pin	1
42	washer	2


Brushless plunge router



Part No. Part Name. Qty.


43	locknut	1
44	router base	1
45	guide pillar end rod	1
46	torsional spring	2
47	Short guide pillar	1
48	circlip for hole	2
49	hexagon head bolt	4
50	stopper knob	4
51	spring	3
52	main base	1
53	flat point set screw	2
54	base plate	1
55	screw	4
56	spring	1
57	steel ball	1
58	guide pillar	1
59	stopper base	1
60	spring	1
61	shoulder screw	1
62	gag lever post	1
63	circlip for hole	1
64	guide sleeve	2
65	Scale label	1
66	Parallel guide bar	2
67	Parallel locating seat	1
68	wing nut M6	1
69	washer	1
70	bolt M6*18	1
71	templet guide	1
72	thumb screw	1
73	dust nozzle	1
74	dust guard	1
75	bolt M6*18	1
76	location-plate	1
77	straight guide	1
78	wing nut M6	1
79	wrench 13	1
80	wrench 22	1
81	battery pack	1
82	charger	1

Brushless plunge router Router base and accessories





اتفرالمس عديمطسالغا التخديد جامسح 20 لتفو
IDU WR-B8
خدمستلا يلد



تفاصيل اموال

لديالمو:	IDU WR B8
قيطو الفرظ الة ردق	6 مم / 8 مم
ة عرض لاديدنليومت	28000/ 12000 -تقدقي
ردق المدجھال	رستم مراتي 20 تفلو
زولناصلايف	1.8 -2.1چمك

- رظنريامبلا انجمالن رمتلاو ئحيوطنوي صاوملا نايفوع انه دئراولا تافلك ؤصود ريبيعتن راعشا.
- قمزح وتافاص الموف تختلقو خأ الي دبن مابراطالب.

حني ات المائلس

يائبركه العدا لائقام العائلس التار ئيحت

ئبرحت : <p>ئيجضينوالاشكالاوتالتعليموالمسالنار ئيحتيعمجاً رقا يعجم عاتبا مدع يدؤو دقو .ئينابركهال ءادالا هذه عمه رفنوالم تافاصالموو و ئينابركه دئم صئدوح إلى هاندئا ذكروالم تالعليئيرج بنشو و\أو ءر يخط ءاباص</p>

ف اليه اء جولر تايملتعا وتا نبرحتلا عيجم ظفقتسلما ي.

حطلمص ريئشي "ءءالا/ لعمت تيال تادوالا لبنا ر ئيحاتل في"ئينابركهال تادوالا ئيسكال(اءبركهال)ببوراتالب بلعم تتيل ا أو ببوراتالب لع عم تتيل ا)ئيسكالال.

مللعا طقئن ميف المائلس

- الجيءاء الضار رفيئوو لعمال قظمن ئفاظن على طفاحءءرغي قظامنا .ابه ئءاحوال ب تسبءق قظلم الم اوئبرالم
- ءجوو لمئ براجفانلل بيقال اء جولأا في ئينابركهال تادوالا لشغيبئ مقئ ال ع و ا تازاع و ا لناوبق رابشالل لبلاعب بئ ركهلا توادالا ئياعراش ئيناب **يأصخشلا المائلسا**
- ءرخاب ا اوراعب ال لاشئع ا البئ دؤو دق
- ءءال شغيكئ اعئئا ءرالمو لافطالا هائيلئا ئئئئ بئسب دق .ئينابركهال هالل اعلى تك رط سيقف تعلقج في.

يئابرهركا المائلسا

- اطم نم دئكائقم قئبوهكلا ءءالا ببهكلا جرخملا عم ئينابوئيمو .ئينابماتي.
- ءءالا مع ليحوت سابقم يا مدخشئ ال .لاشكالا نم لشك ياب سابقال لئيدع ئينابركهال قضر المواقملا حماريغ ببهكلا جراخملاو قظلملا ئينابيقبلقئ لا رطخ ئيعيئو هكلا فقصلل ضريناب.
- ء زجهأ و بيابئانلمئ قضر الموو أو قضر الموو حطسلال مسجال تسالمم بئجن تاجائئال و قئئئلا ء زجهأ و قئئئئءا ئينابركه ءئمصلا ضرئعل رطخ دءازي رؤوم كسج نالئئن رؤوم واضن.
- هالمئ لئوؤ دوزي .قظورال فوزظال او رظلم ئينابركهالا تادوالا ضرئع ال ركهلا ءادالا بلاا رطخ نم ئينابيعيئو هكلا فقصلل ضريناب.

- ال سا عئسوئوهكلا كلسلا لامعئوئعم .ئينابماتي ءءالا لمح ا أو ئينابركهال أو محوشال و ا ءراحال نع سلكال دايع .سلكال مءاسئب افصله أو اءببس ءكروءالمء اء زجالا أو ءءاحال فاحوال نم ئابكئئالمئ أو قئائئل كسالا ءيزئ لا رطخيئو هكلا فقصلل ضريناب.

بسانم دئيم سلك مءاسئب ،قطلءا اء البو في ئينابركهال ءءالا لشغيئ دعن خالئسلءءجوراخال قظاملل يف مءاخالئسل بسانم سلك مءاخئسا .جيراخال مءا لا رطخ نم لئقيئو هكلا فقصلل ضريناب.

م ال ئاك اءيم رفرهكلا ءءالا ليغئئيقئاب .بطر ئاكم يف سناؤوم مءخئئا بيمجرهك ءرئاء عطاقك لرا ئينابوهكلا ءرئالاء عطاق(قضييعمال ئينابقب ضيورال)رطخ نم ضيورالا ئييمعال ئينابركهال ء رءائال اطعق مءاخسئ لئلي ئينابركه ءئم صئءوح

ءاطيسيمغوركهئااچئينابركهال تادوالاچئئنئمئكي)قوئال ءاطيسيمغوركهال(مدخشئلل ءراض رغي. دئمخئسم على بجي ،ئلك معو خالا قظلمامل ئييطال ء زجهال و بقلال ئابرض منئظي ء زجهالالاصئئصاب ومئزجهأ/ ءءالا هئمشغئلقب ءر مشوالعلللمصوببيطالأو

ئينابركهال

لبرءح ريقو فئل هيموقئساو هبءع ميسلا سءلاو قطنملا مءخئكئيمئئ ركهلا ءءالل. ئينابسيءهكلا ءءالا مءك اء ئينابي.قهرم ئقو ا ا ءئئاؤئؤ قئدوال ا أوئايحو الك أوريقائعل . تادوالا لشغي ئامئئا ءءءا و قظح للقالع رهكؤئي دق ئينابي اصلا بلا قئب ئيصخش قريبطخ.

مءاعم مءخئق مئاء صرءا .ئيصخشلا ئيماحلا ئا رابلعل ءاءئب قئامح ئارا نالعي.الزلالن ءابقوال رغي ءالمسال ئئءيا أو راعبال مامك لئم وايقلوا ءءامقئ سئسمع ئالقاي و أوئصلب القئيع الأو ملقئ قضيخش ئالاب(لصا) ءءوح ن.

فقاقي ضعمو في ءافئالم ئا نم ءاكئ .ءصوالم رغي لشغيائئ نعم على صرءا أو ،ببوراتالب قمزح بيكورت أو / و ققاطل رءبمص سابقال ليصئو لقب لشغيائئ ءءال اللحم و اطاق ئءدن. ءءوال اللحم ببسئئ ن نمكئياصبع و ئينابركهال ملا بلهيا حاءر هكلا توادالا ئيشئئلا ئينابئحيئئوي ء بلعلا ئائءلبئيبف ئءا حوالع قروو طضبء حافظم يا لرا ئينابركهال ءءالا لشغيئ لقب طور ءافئتم أو. هئئ ئئي ملا ئي ءا قئوئئئبمبلا اءه كرفقلمع ءائووالا ءءزجالبةاللابوعوو يف ءصئخش ئالاباص.

- اچراوت نلع طف ئ نلع صرءا ،كن لاءو مءقالا نطوم ئانابوئئعيمج يف ئاقالوئكئئبلا كنئكمئحيءو هكلا ءءالا بئقئيابا لكئئبليصفقفاوملا يف قئعئولم ارغي ءاچئفالم.
- وئئالمائل مئئاملا سبوهكلا ءءالا ليغئئلل .ئينابوئالم بئئسيءئقضا؍ ءك روحالمء اء زجالا نع سكماليو كرشع ءابع على صرءا .ئارءجوم.أو جولالم أوءاضففضال سالمالب قئعل ئا نمكئ في ليوطولا رئعالم أو ئاره ءكروء المءء زجالا
- اصبئهوئ نم ءاكئئ ،براعبال يعجمئو قفش قفام ر ليصئولئ ء زجهأ رفيئو مئ ئاا لئقئئ بل رابالع معجم مءاخسئ يدؤو ئا نمكئ .ءيحص لشكب امءاءاسئو راعبال بئقلمئعل ارطاخلالم.
- ررئكالم مءاخالسئا نم قئكئئبئال قءاللا عئءال اضربالك ءسئمئ تاءولأل ءعض في ءرخطي ءابلس في بئسب دق لالهلما .ءءالا ءالمس ئءامب لاهئئئءءا أو ببوراتالب ءءوو مدخشئ اللقال أو قئالئئ ئابوراتالب رطهئ دق .ءلمع أو كولئس قئلمءاربع ريقوئئوئح بوشن هنع ءئئئا وأ قئصلاا رطخ وأ راجئقب.

الابهائيلعن وئينابركهال ءءءال مءاخسئ ءءالا مءاخسئ .هب مءايلل مئمص مل امم ماقبلا على ئينابركهال ءءالا رءجب ال ءململ ءاسيالم ئينابركهال.لغضا لشكب لعمال ئينابركهال ءءالا زءئسئ كاؤنمأ ربقا لءمصلاب بئلا مئمص نم هلجا.

- فقاقيو اشغئلبئئ موفقي دبع ملو ءاقلالم قئل ئاا ئينابركهال ءءالا مءخئسئ ال اشغئبئبئئو هك ءءا يا رئئئكمئ ال ئينامكئئايفسايملامءاخفقءاا ءائق قريطخومزلي امءالصا.
- فصاو ققاطل رءمص نع سابقال ل / ققاطل رءمص نع سابقال لصفب مق أو لئوو ركهال ءءالا نم ،قطنلل ءابق ئائك ئاا ،ببوراتالب قمزح ءالزباب مق أو ئئي .ئينابركهال تادوالا بئزءء أو ئاقلملاربيئع أو ئئبائئع يا اء رجا
- شائئ رطخ نم ءءال على ئئيقالو ئاءا رجالا هءه لئم لعمئلال ئافءالم لغي.
- مؤنبيءئر هكلا توادالا ئقظلمعلا ئينابديعيمي م نع لئالا لوانئو لافءلمئئ ءءالا لشغيئب ئائمئعملل هءه أو ئينابركهال ءءالا بئلملمارغي صاخشائل ئينابركهالصئئوهكلا توادالا قريوطخ ئينابي رءملا ريغ بئءيا بئقئيب.
- يأءجوو مءع نم قئقئئ .ائئقلملو ئينابركهال ءءالا ءانصي على صرءا .ءا زجالا بئي ضرائئع أو قئقئرءالمءئا ءو قءعال في رس كئيا ءجوو مءعو رءا ءلاچئئ ءؤئ مق ،افئئل ءالء في .ئينابركهال تادوالا لشغيئ على مءاخالسئلقبئينابركهالءءالااإصالب . الءانصيء سوبيئسب تاءو

- ئءا حوالن مءءي العفي ئينابركهال
- ءءاحال فاحوال ئءا عطقل تاءوا إءئهوئ القئع تاءوا قفاظن على طفاح لئبئقئئص مئئعئءيحص لكئئبوئكئ رء نقل قض لهساو قئئلا بفقكئ ابه.
- وهكلا ءءالا مءخفقلمو قئبابئ كلئ امو ءءالا مقلو اهقئب هءهل ئامئلئء، مع مءاخسئ يدؤو ئا نمكئ .هئيقئن ميئئ بئلا لعمال لعمال فوزظءا عارم رخطي عئض وئ لءقضمو المئك نع قئمخئئئ ءامئلي في ئينابركهال ءءالا
- ئيو زالم ءالءو ققظوو قفاج اكسالما قسطا و ضاربالم على طفاح الاء عم ئانمأ لمءائبئ اكسالما قسطا و قظزال ضاربالم ءسئم ال .محوشاؤوا قعئو المروي ققالمو في افئيه مءكائو
- سا دئق ،ءءالا مءءخئوئق بئئئلا ئئيماقملا لعمال ئاز افئق بئوئكئئبئئءكب.
- ءاباص ال ئكرلمءئا ء زجالا في ءاشئقلملا لعمال ئا زاقق اءكئئ يدؤو دق قصئخش.

ا بهيةالئلع ويةارطبلا امءئئسا

- ءالمصئ قءرئشال لقب نم ءءالم بئئشائل مءاخسئب طقف ئعشال ءءا . رطخ ال ئابوراتالب مزح نم ءءاو ءولن بسالمئن ئعشال قءئئ ئا نمكئ ءمع ءمءاخسئ دعن قيرءبئئشوراطب قمزءا ءئيءءالا مءخئسئ ال

ر هكلاا ئئبائئلا عراطبئئاي قءصخشلامل . يا مءاخسئ يدؤو ئا نمكئ راطبئرءا ئايي اصلاا رطخ بلاءاو قئقي لءنع سانع قفوئلا لامعئواطب،ءقئبئديعيميبرءاخالا بئئءمصلا مسجالا نع لي الم أو ئئي مءعالم تمالع أو ققور الو اءكئشالءقلملئوئالب أو رامئسالم أو ءئاف رءا قريغص قئئءعم مسجا يا وئئا انهكمئ . فارظالا ءءا لصئئوخالاب. ي ءقئئبب لا فارظا ليصئوئواطبعم ئئي .ورء ءوئح يقق روح بوشن وأ قئ. بئقئئ بببوراتالب جراخ لانسلا قئئئئ دق ،ئئسالم لاصالئسا فوزظئئئ ئامك لسعاف ،اطءال قيرطنع هئسمئال ءالء في .لانسلا ءاهئسالم ءبع ئييطال ءءعامل طلب مق ،نالعي لانسال سالم ئاا ام .اءالمب سالمائ ءالمب اسلمغ . قيراطبئا نم هءا رءامئ بئال لانسال بئسي دق ءئوح في ورح و ا ءيئقئ.

أو ببوراتالب ءءوو مءخئسئ اللقال أو قئالئئ ئابوراتالب رطهئئ دق .ءلمع أو كولئس قئلمءاربع ريقوئئوئح بوشن هنع ءئئئا وأ قئصلاا رطخ وأ راجئقب. الاء مزءع ضرباطبئوطل ءءالا و الئئيءئئئلا ءرا ءراحل ءءرء و ا في قئئض أو ئارئئئل نم علءا ءرا ءرء130 ءئوح في بئسب دق بئئوم ءءرء راجئفان.

جراخ ءءالا و ئببوراتالب ءءوو ئعئئئ الو ئعشال ئاءئعلم عجمئ بعائ رغي لشك ئعشال يدؤو دق .ئا ءئلئيفي ءء المءا رءرء ءءرء قاطئن قيراطالب قئئ ال ءءالم قاطئال جراخ ءرا ءرءءرء في أو ءصئي ئئشورطخ ءءاوؤي رءب.

تلمءخال

قئع مءاخسئئب انئئاصئل لهمو صخش لقب نم ئينابركهال ءائكا ءئاصيب مق طقف ققالبط مرأيئبببوراتالب ءءال ءالمس على طفاح للءكئو ال مقئئوب لا ئاءوؤ .ئئاصبببوراتبلا ئافئقف .طقف ئابوراتالب ءانصي بجي ق قءلا ءكرشال ليئصن عملا مءءءلا بمءقم و ا ءءئمئئ.

ربيئع ومشئلئئئ ءاعئلم بعائ - ئاقءالم.

محوش و آئيوؤ ءئي ءالمئغ و ققظئي وقءاج ضباب المعطئ طفاح

سلكى الالبئئئئ العائل المئس التار ئيحت


ءحسابب ئينابركهال ءءالا سكام .سالمي دق اطعقال ئال ،قورزمعال اكسالما قئيقالم كسالا . سلك قئع يدؤو دق ئئبئمءا ء زجالا لعج بل "بركهيم ئينابركهال ءءال ان مءقكئشوالم بببورشع للمءءص و . اوبملا مءءئرط يا و ا طبوءا قئلمع ققئهلئئاممءوو لمعلا ءعطق ئئبصئمص بي قئعق ال سكم يدؤو ئئي .ئئئئك مءع ال مسجال هءاؤئ سءك في أو ءئك اعطيه ءرط السبئقف و اءرراقبئب وقئبقوؤ لايء عملل ءءقئرئمصلا ليغئئئئئ.
- قءائف قئبابمئ بئوش السئقؤل مع لاءئع.
- لا مقل صءبئئئشئقئابئعبئبئو قئئلا نع ققلا و اق قئئلا لبمئا .ليغئئئئب على قئئال الو انقئئش المءءلللقئر فوال.
- لقب لعمال قئعق نم بريامسالم بءجم لرا و صءفا بريامسالم قئع بئجن لشغيائئ.
- مءكلا ببءءال اسكام.
- ء راءو الاء زجال ءك نع دايع
- ءبائئ المئشئي قئالب لع المئطقق سالمئ ال بئئش ءئءا انقئم لن أن ءءاكئ.

يفيظولا صفولا

هبيتن مهاد دكبي فاقيا نم لا تدحو ولازوا نادالا ليغشتا طبق فيض لطلب
اقتهبط ون مقوق الت أو دالالا.

اهتلاز أوة راطبلا حدوة تبيثت

تقاد مق: هبيتي فاقيا بق نادالا ليغشتا تدحو وأ بيكرت
في راطبلا حدوة
راطلب و دال اسكام هبيتن
في راطبلا حدوة مدح يدوي. اتهالزا أو اكيبهرت دعن ماحكبا
بال بيديو ويكي نم اهمفلا زان إلى ماحكبا في راطبلا حدوة و دالالا
فيضين فاقيا و في راطبلا حدوة و دالالا



▶ راجح أرش مؤ 2. رز 3 في راطبلا حدوة


في راطبلا حدوة و دالالا نادال ان ماحيس في دجو المورز اليكرحت لخال
تسطورخ ان مياهم اء زجال

معتوراط اليتح و على دجو و المناسلا دذاح بمق، في راطبلا حدوة ويكرت
مق و نبي المفى دجو المودود خلت تبح لامالك باهخلد اهانمك في الخداب
في ابتيهطى رحمال ارشو المتورز نكامكبا نا كذا اء ري صغة رفن بانهمك
ولعلا بناجلي رزلا نم، قلعغ ريغ بيغما ميا.

⚠ متاد مق: هبيتي ابيتلا فمزح تبيبا طبق لமாகلا بيوتو رذعي
ن ماطخ القيرط نع طقس يبقف، ذلك كرم ان يكم لذا ارحمال ارشالمو
امم، دالالا كو ن مصخش ل اولك ناب اصفي بيتب.
قول: في راطبلا حدوة ويكرت مق تال: هبيتن
بتراطب اليتح و قلزن تم لدا ليح سلكك بالهخدا ميت نفل، تسهور.

تقيبت المعتوراط اليتح لى اء ارشالا

رشالموب تدوز المتاوراطب الحدوة لوطقق



▶ لرش الموحيا مص قخلت ارز

تسع انة ارشال لمعتوراط اليتح و على دجو المورياتخال ارز على طاضغ
ناثو فيض لرش الموحياص مي، تض: تقيبت المتتي راطبالب

تظومل: عامتي سالا فورظ فظلملا فرارحلا تجردو مادخت،
خي دقالبق رشوملا فظلملا فرارحلا فظلملا

لدوج التي تقيبت المعتوراطب التمع و حياتف المتع لوعلى حضور مع العالج الرظيت
الى الت.

رش موالج اللي	تقيبت المعتوراطب اليتح
	اليحو 70% ر اناؤ
	اليحو 80% - 0%
	ن ملق اليحو 20%

تاظملا:

تقيبت المعتوراطب اليتح ن مقق التتقب: دال افاق اين مذاك ت.

بادال اءايح ماطن في راطبلا حدوة

متادالا زيهجتلا / دالالا قيامح ماطن ماطن ماطن اذ موفى، تقيبتا تقيبت
رعم الطال كرح الموع فظلملا راطبال و دالالا في قوتيا قوتيا لايخ ا
قيل التطور ش الحدوة أتح تتراطب الب أو دالالا اضعمو تذا لشغيا لتي
دانزل الحدوة ميا ميا
في امنعت لا ليغشتا طبق فيض لطلب ليجعت بجستو ابيتر مفا ريع لكشب
طبيعت: دالالا في قوتيا قوتيا لايخ ا رشوم يامق، دالالا هذه في فاقيا ليشغيت
لشغيت مق مئ، دنناز لكش بدال الحدوة في تسب يذ المداخسا فاقيا و دالالا
لشغي التداخسا دالالا.

10. تقطعي لعم تقطع على دالالا امداح استلقببق اللون مرة لعمت اكهر اب
رغي لكشك رفحلا ة لقميتبت ابر يشيدق يذ البذنب الت اوزا ز هتال ابقار
حصي.
11. رذح نكيا نك لعمل نارود هاجتاو بيذلك هاجتو عت.
12. مق. لعمت نال اكرت الية دالالا ليغشتا مدغ طقوكتن قلمو محديلاب.
13. مناد مق لا فاقيا بنوا ليغشتا رظت متلا مقفل قوتيا بيذشتا ممتق ة لازا لب
لعم التطقن م دالالا.

14. الة مقفل سلمت بيذشتو شايغ ليعلا دعب قفوكتي في اعلا تنحاس نكي
نرحتو شبكت.
15. بال دالالا دتعاق خطل ال ام أو تيزال أو نيزبال أو فخال مبال ال
دالالا دتعاق في تاقش تدهو في بتتسب دق، ذلك هابش.
16. بال اءعر سل بسالمن ح الحيقاس الرطو نذا بيذشتا التيق لمدخاست.
17. حيتويق فينايمك داوم بلع اوما ضعيوكتن ماس عمل رذحلا بخوت
دجل التسال م و راعب القاشستسا المويدر موة المئ تالتي بعثيا
18. راعب القيا و مدخاستا عليه لعم تي التيعمال و دة للماسب المتامكم ال.

ت هذا ليعتلا ليلدب فظتعا.

رذحت: جتالمن المالمو قحارال عدتال (مداخل استام بيسالمتك
ماز للتا لحم لحت) ر المئك ليعال جتلمن المسمال دقاوب مرصال دق
اعليه صصوالن المسمال دقاوب عتيا مدع أو مداخل استا سو بيتتب
ة رخطي تصخش قيا اصدوح في ذا هتا التعليلدلي في

يومرلا

هذا لادمخست الزومر البلي ا محضيو


تلفوال	V
رشا المبراتيا	---
ءعر سلا دبن ليمحت	n ₀
تقدي القيا تديالبت اوة رءو	.../min r/min

في راطبلا حدوة رخة لماهال مائل السال تايملت


1. في راطبلا حدوة رخة مداخل استلقبو رذح التتالمع و تاتعليل العجمي ارق ا
على دتجو الم (1) و في راطبلا حدوة (2) في راطب (3) يذ الجتالم)
في راطب المديخت.
2. في راطبلا حدوة رخة كفت تال
3. لكش برقص اليشغ التتق و حصب اذالا على لشغيا لتي نع قفتوف، طرفم
لا رطخ بلا كلذ بيديو دق، و رويو فظلملا فرارحلا تجردو عافو جمالمت
راجفان اتيحو.

في راطبلا حدوة مراع بصفا نغ ظافحلل حناصن

1. مولا مشوطر خ نحشوا طبق في ليدت فلعغ هتاد مق، لமாகلا بيا فاقيا بليغشت
في راطبلا حدوة رخة نحش و دالالا دالالا قاطض افخ ناطح تال مدغن.
2. ال مقنيتا فدحو نحش دة اعينجش البيذوي، لامالك بتحوش معتوراطب
في راطبلا حدوة رعم صيق تال دالالا
3. دعن دفر العة رارح تجردو في راطبلا حدوة رخة نحش 100 فينو متجرد -
40 فينو متجرد (50 تايهرفه تجرد - 104 عد)، تايهرفه تجرد
انحش لقب درب ت تنحاس التي راطبلا حدوة رخة
4. تسطورخ نحش تيسقن مراكش (قبطوة رف ت لامهدج تستمل ذا ا في راطبالب
رشيا).




► 1 لفق دعوام 2. كفال 3 بطور لل 4. غيار رب حاتم
5 ة اللقم للصمو



► 1 غيار بحاف م كفال لل 3 بطور لل 4 ةقم للالصمو .


تظهومل: ةلاموص طبر دعن بالصلا عضالمو الى دعومال لفق دبعو ال دق
وطلاق لا تمقل بيكرت دنق دوعي بيذشت بصلالا عضوملا بلإ دومعلا لفق
ةدال الشغي تده بدعن.



► 1 دعومال للفق .


بيذشت الةال ددعاق ءالز او ابكورت

1. بيذشت الةال ددعاق لفق عارذ حفتالخد ام شةال ددعاق في ءداللا
ةال ددعاق على دجو مو الة نو ان معة دال اعلى دجو المودوخال اذاح لميذشالت
بيذشت.




► 1 لفق العارذ .


2. لفق العارذ قفلا
3. بيذشت التةا اذعاق براب الةهفو لصينو بمؤطر ماككا بمق م ث
م البه اغي رب



► 1. اسمي البغور برابغ التياوح




ددعاق الةال زالمعكال بيكرت التاه رج ابعث ا




► 1 اذداس غور ب 2 دذيغ الرز

8. قعم لفقيد طضب اه رج قلع ال دعمو على صرق الرد اذداسال
الرد بيثي ثجي "0".




► 4 صرق .

9. بطلو المقعم العلى لوحص للذداس الدعوم سار رذعم التايز له
قعم اللق لت. عاس البراقع هاج اتسعك سار الرذهاجت افي سار الرد ا
عاس البراقع




► 1 دعومال سار ءداسال

10. ءداسال الدعومال بيثب تةلامو صطورا



► 1 بيثب التةلامو ص

11. بيثب العارذ بفق مقي



► 1 بيثب التعارذ .


بيكرتال

هيبين مناد دكاتي فاقيا نم لا تشوطر خ عزنو ءادالا ليغشيتواطي ءيافلا ل
ءدال اي عمل لم باب.

بيذشت الةال لقمه الاز او ابكورت


تظومال: الطلا ءلوماص دشتقودن لاخذل تمقلار سنك يدق
في طو الطور حالم

لا تمقل لخد ا رطل لوط بلع بيذشتقي وطلا طورخم يفق بلع طغضا . لفق
راو دوموطلا ءلوماص طبعقلا فوا وا حيقظلا ءلوماص طبعقلا كحباب
رفق اللقم للالزال. ناحيفت الممداخاستبهاجالت افي تيثلت اه رج ابع ات
ساكمعال.




▶ إلفق العارذ . 1

8. غيار ب الطبر قيرط نع تدعاق الةح لولصيتو ببق




▶ 1 بتدعاق ةح لو

9. وطلا طورخم لخدقلا تادا تمقلو بيذشتتجازإلا تدعاق يفمكحاً مث وطلا ةلوماص طبق.




▶ 1 بيذش التة لقم ة2 للقمائل صمو. 3 وطلا طورخم ق

10. طبر محكاً مث، تجازإلا تدعاق تحفت في داسيسال طبرال حافتم لخدأ وطلا ةلوماص ق سابع مادخفقلا حانطب.



▶ 1 ة اللقمائلصمو ةبغير بحافت مةهيسال طبر ال حافت م تدعاق الةال زالمعكال ببكر تاء رج ابعث ا


ظهورم: ضياً كتكمي الا بلع مازحلا بيكر تة تركلكم تدعاقلا تحول ةلازإ لشك الفى حض موهو.




▶ ةريك 2مازح .

سط التدعاق ةالز او ابكرت
خا قحلو ابتي


1. على سبط التدعاق في ةدالالا لخدأ امث، سبط التدعاق لفق عارذ حفتا نعل دجو المودوخال اذتاج لمقيرط اللطوطى دجو الموزور البع مةدالالا سبط الةتدعاق.



▶ إلفق العارذ .




▶ 1 ة اللقمائلصمو ةعمول الفق . 3 غيار بحافت م
2. ميقتلا ةلوماص ةلازاب ميقتلا طورخم ق.



▶ 1 ة اللقمائل صمو 2 وطلا طورخم ق

3. دعمو اللفق على طضع القيرط نع ةدالالا اعلى ةريك ابكرت مق طبر الحافت م ةر البكطبر ماكبو




▶ 1 غيار بحافت م 2 ةريك 3 دعمو اللفق .

. تدعاق الةح لوعلى دجو الموعيار البيفك مةجلو ةلازاب مق م ث تدعاقال.


▶ 1 بتدعاق ةح لو

5. تجازإلا تدعاق لفق عارذ حفتما زإلا تدعاق في ةدالالا لخدأ م ث



▶ إلفق العارذ .

6. على مازحل ابكرت مق لاطنع تركب قيرط م مازحلا رةي ا.




▶ 1 ةريك 2مازح .

7 لفق العارذ قفلا

سمللا ليدلا مادختو نادلا لمعال ميقتي

سنلايدنادلا لمعال تبيحوق ميملا ليدلا عيمجتضوم وه امك ميقت لاكشالا يف.
رطق فنص لفصنال ادحال ويندال ادحالي فاسلما (اعطق دار المرادوال
يلي ام هي)ة اللقزكرم وة ردائ الزكرم
• نندال ادحال: 70ممل (2- B-4صوبو)
• فصال ادحال: 221ممل (8- 11-16صوبو)
نبي راندو اللقاع 70 مم (2- B-4صوبو) و121 مم (4- B-4 في)صوبو
رطق الفنص.




1 ▶ راسم هيزكر المتحفت ال.

دبمع اللدلي مداخاست


خا قحلو ايدي

حسلفمك القاع بدالمعب لادلي د المعب مداختسا دبمع الطا اتمع مرر.
1. ددعاق لوحى تدجو الموعيار البيفك مقلو فالزاب مق م ث
بذيش التال ددعاق ن مدعاقال.
2. دح لو تيبنت مق م ث، ددعاقال على ريامع التحفص لادلي ضع
غيارب الطير ماحك اقرط نع ددعاقال



▶ هيزكر المتحفت ال


نبي راندو اللقاع 121 مم (4- B-4) و221 مم (8- 11-16 فنص في)
رطقال.



▶ هيزكر المتحفت ال


تظحول: نبي راندو اللقاع نمك بال 172 مم (6- B-4) و186 مم
(7- 6-4 لي اذا همداخاستب رطق الفنص في)"

لدليلال في هيزكر المتحفت التذاح بمقورلم اة ردانال زكرم معقميستال
دا . اعطق امسم عيب نم لقا 6 ملم (1/1 هيزكر المتحفتال في)صوبو
مقيمت الهج المون امي لت.
mmعاس الجرافع هاج اتفي رفظ اللحو ددال اريدويت مق



1 ▶ ددعاق دح لو 2 ريامع دحفي صلدلي .

3. رحو غدصلا بلع دادالا عيزرنا عم دادالا ك بلع غدصلا ليلد قال
ذغ الصبانج.




1 ▶ بذيش التة لقم لعم اللقاع . هقيمت لادلي .

تظحال: رظيلا عطقلا تالها دق طرفصص وا كرحمال دنانلا لمحلا ببببببب
نع اللقاع قعم ديزي ال ايجي ، ددالا في محكالت 3 مم (1/1 بر التم دعن)صوبو
ددياخال قطع دعن . نمر اركت قعبد ددياخال قطع في بغرت ادمنع 3 مم
(1/1 هم ات بتداداع اع متا روير التمن مددي العاء رجا بمق ،)صوبو دديجي ا.


مقيمتل اللدلي مداخاست

خا قحلو ايدي

1. تجمن الالوالمص وراسم المع مقيمت الهج المويجميت مق




1 ▶ راسم م 2 تجمن قل صمو.
2. غور بمداخاستب بذيش التة دادا ددعاق بمقيمت الهج المولصوتو بمق
طقم.




▶ اطقم غورب .

3. بفك مق فاسالم طضباو مقيتسال هجالمو على تجمنال الالوالمص
الالوالمص طير مكحا ، تبطلوا لم فاسالم دعن . مقيمتال هجالمو واللقم نبي
تجمنال.




▶ اجمن قل صمو

4. تطق بانج معقنت بيد المقيمت الهج الموداخاست بالال اكرح
لعمال.




تان كذا! فاسالم A) دح عساو عطقلا عضومو لمعلا عطق بانج نيبيا
مقيمت اللدلي للالتبيب، نمك يقال ، مقيمت رغي لعم اللقاع بانج نا كذا ! او
مقيمتل اللدلي مداخاست.
لدليك امهدخاستو مالع كطعطب ماحكاب مقيمتس كدلو تيبنت مق ، لالاحل هذه في
قال ددعاق لاقم بذيشتال . مسه الهاج اتفي ددال ادنيغ بمق.



⚠ تنعيب هناد دكابت. فابقيا نم ليغشلقب قيراطب التالاز! وهداالا
التصميم ال اوصحف الاء رج اءلاوح
ال: قظلالمستقطم مدختيلا وا، نيلوزاجلر نيلوا، نيلو، حكلا وا، برنت
اش امهنا دق. كلذ هب كلذ نع جنسو بعتوللا يقن ووا هوشت تاقتشت.


تقيتو مو وجنت المالمس على ظافل هل هي أو تاحالالص اء رج ايج ي
تدمخ زاكم أو تدمعتم التدمخ الزاكر ملقب ن مرخا لديع أو تصمص
مناو، عنصملا لميلادخت عطق رايعلا قيصلا.




نعاش العلى دوح البدجه ال طقف مدخاست.

مقلا نحش لنواطية مق، قظلالم ليصوت ققطالا لنيلو، حكلا رايتيماق مت
لامكال بتيراطبال نحش دبع. نحاشال بتيراطب التمزح لصيتو ببرد مصلفص ا
ن متوارط البتمزح تالاز اء بعقاطال نحاشال.
• اورط المواء المينج تيج ي طقف داخلي المداخالست لزاچه الذاه
تطورال

• الو رطملا نحاشلا ضرعوتجلا فورظلاو جلتوخاللا قيساقلا قيوال بسندخت
اء مراخ بنا به او قظبر ناك أمقي قتيابركه القادوا لا
اوهطوس اوة قروب برض للهضرتع فالج في نحاش المدخ تستال يا بيهقتل
دمعتم الء عم تدمخ زكرم للهدخ، لاشكال ان ملشك.
حجمال الى تجاحب ناك ذاا الء عمال تدمخ الى هرخصا، نحاشال بفق مقت ال
أو قتيابركه تدمص ثدوح بال حصيلال ري بعجملنا بديو دق، تصمص أو
قيرح بنشو.



ظلة حولم خيلا عطقلا مجج فلت البلق لمعلا عطق بلع بلعني ص نيجيف
لا. قيراصلاق اسملا ولا قظلفصاف (X) مي جراح الء زجال وبذيش التة لقمني بن
قفاس المباسح نمكي. اء رايع القحفي صلدنلا (X) التة مع المداخالست ب:
قفاسالم (X) = المعبدللي لجوراخال رطقال- التانم لطق بذيش (2/




▶ 1. بذيش التة لقم 2 قفاسلم اء رايع قحفي صلدنلا (X)

بجرايع قحفي صلدنلا لجوراخال الرطق ال


ة رايع قحفيص لدني مداخالست

خا قظلو ايتي

قيرط نع ثالاثة رشقال لمث نيجلمنا بانجال بذيشيت بذيشالت فال لدني حسمي
تطعق بانج لطقو على هجيتو التة ر بيكر حنتلعلما.




بذيشالتتط القمغور بطبر ما حكاب مق م ث
بذيشالتتط القمغور بطبر ما حكاب مق م ث




▶ 1 طقم غير ب

2. قدا التدي وبذيشت التة اء لقمني بقفاس المظضبا وط القمغور بيفك مق
طب الضغور بريدو ققورط نع بذيشالت (1 مم) 4 B عن. قف لللك تصوب
قبطلو المقفاسل بذيش التة اء التدي تيشلت ط القمغور بطبر محك أ



▶ 2 طقم غير ب

3. لعم التطقق بانج بلع ر تسيبي الهجيتو التة ر بك معادل اكرج



▶ 1 لعم التطقق 2. قفاسل هجيتو التة ر بك.